

Offset Installation Instructions



legs on back should be on **left** side when installing on driver side vents



legs on back should be on **right** side when installing on driver side vents



Use for:

- Jeep Grand Cherokee 2005-10
- Kia Sorento
- Porsche Cayenne